



Body Highlight – Loose Powder with AGENASORB DRY RICEGEL NS 9095

“developed & formulated exclusively by Eckart for CLR”

Ingredients	INCI-Name	%w/w	Supplier
Phase A			
Synafil S1050	Synthetic Fluorphlogopite	46,00	Eckart
Baycusan C1005	Methoxy PEG-17/Methoxy PEG-11/HDI Isocyanurate Trimer Crosspolymer	6,00	Bayer
AGENASORB DRY RICEGEL NS 9095	Glyceryl Starch	10,00	AGRANA
Mirage Bright Gold	Calcium Sodium Borosilicate, Titanium Dioxide	20,00	Eckart
Mirage Sparkling Champagne	Calcium Sodium Borosilicate, Iron Oxides	14,00	Eckart
Phase B			
ProBioBalance CLR™ NP	Water, Lactose, Milk Protein, Bifida Ferment Lysate	2,00	CLR
Labrafac CC	Caprylic/Capric Triglyceride	2,00	Gattefossé

PROCEDURE

1. Mix phase A with speed mixer (30s/ 2000rpm).
2. Add B to A and stir again with speed mixer (30s / 2200rpm).
3. Fill into an appropriate container.

*) This formula has been manufactured and stability tested using a special preservative, but has not been subjected to microbiological challenge tests.

The recommendations and formulations given are based on our knowledge and experience in the field of technical application. They are, to the best of our belief, correct, but are offered without obligation. Those who use our recommendations and formulations as well as those who process CLR Active Agents are themselves responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies.