

# AZÉLIA ON FIRE

## AQUEOUS Gel for fun freckle effect with AGENAMALT 20.235



”Formulated and developed by Azelis Personal Care EMEA (ref. 230616.06)”

This aqueous gel can be used to give a fun freckle effect.

AGENAMALT 20.235 has been used to enhance drying and give a second skin effect.

Ingredients	INCI-Name	% w/w	Supplier
<b>Phase A</b>			
Aqua	Aqua	37,45	
Blanova® Trisodium Citrate Dihydrate BP/E331	Trisodium Citrate Dihydrate	0,05	Azelis
<b>Phase B</b>			
Glycerin Palm Free	Glycerin	4,65	Stéarinerie Dubois
Blanova® BioBG	Butylene Glycol	4,65	Azelis
GENUGEL® CG-130	Chondrus Crispus Powder	0,47	CP Kelco
GENUVISCO® Carrageenan CG-129	Chondrus Crispus Powder	0,65	CP Kelco
KELCOGEL® CG-HA [E]	Gellan Gum	0,19	CP Kelco
<b>Phase C</b>			
Ronacare® Sodium Benzoate	Potassium Sorbate	0,47	Merck
Ronacare® Potassium Sorbate	Sodium Benzoate	0,23	Merck
<b>Phase D</b>			
<b>AGENAMALT 20.235</b>	<b>Maltodextrin</b>	<b>13,95</b>	<b>AGRANA</b>
<b>Phase E</b>			
SensiOp White Co1	C.I.77497, Boron Nitride	10,65	Sensient
Unipure Red LC388	C.I. 77491	0,72	Sensient
Unipure Yellow LC 188	C.I. 77492	2,23	Sensient
Unipure Black LC998	C.I. 77499	2,16	Sensient
<b>Phase F</b>			
Purasal® Moist XS	Aqua, Sodium lactate, Sodium Gluconate, Benzoic Acid	2,79	Purac
Plantasens® OP 95	Sodium Methyl Cocoyl Taurate, Glycol Distearate	1,86	Clariant
<b>Phase G</b>			
Ronaflux® Foxy Red	Silica, C.I. 77499, C.I. 77491, Carbon	0,89	Merck
Colorona® Tangerine Orange	Mica, CI 77491, CI 77891	5,20	Merck
Colorona® Blackstar Red	C.I. 77499, Mica	7,15	Merck
Colorona® Beige	Mica, C.I. 77891, C.I. 77491	2,99	Merck
<b>Phase H</b>			
Purac® HI Pure 90	Lactic Acid, Aqua	0,60	Purac

### MIXING INSTRUCTION AND PROCESS:

Prepare A and heat up to 80°C. Premix the ingredients of phase B and add under stirring to A.

Once the gel is homogeneous, stop heating and add the salts of phase C.

Prepare D and add under high shearing using Ultra-Turrax. Once the mixture is homogeneous, add phase E.

Add ingredients of F below 40°C, one by one. Add G. Add H.

### PHYSICOCHEMICAL INDEX:

Appearance: Thick brown ink

pH: 6.5 -7.0

Stability: RT: RAS at M+1, 40°C: RAS at M+1

### TO USE:

Use a small brush to add freckle effect to the face or body.



AGRANA Starch / AGRANA Stärke GmbH Tel.: +43/2852/503-0, e-mail: cosmetics.starch@agrana.com

This formulation is indicative only and no responsibility whatsoever will be assumed. This formulation is offered solely for your consideration, investigation and verification. It is your responsibility to thoroughly test any formulations before use. All those who use our formulations as well as those who process AGRANA Starches are themselves entirely responsible for the adherence to prevailing statutory regulations and the observance of patent rights as well as other protective rights for other companies. AGRANA does not assure any liability with respect to the composition of the formulation or the use in products.